

# Hidden Mickey Magic Touch

by Props88

## Quick Start

- Tap once → Lights + random sound
  - Tap 3 times → Favorite song + special light show
  - Hold → Adjust volume
- 

## Full Instructions

### Single Tap

Tap once to activate the Hidden Mickey.

- Plays intro sound
- Followed by a random track
- Full LED light sequence runs

### Triple Tap (Secret Feature)

Tap quickly 3 times to activate Favorite Mode.

- Plays your custom favorite song
- Runs extended premium light show

### Long Press (Volume)

Press and hold to increase volume.

- Step-by-step volume increase

- Sound feedback when idle
- Special confirmation at max volume

### Set Your Favorite Song

1. Remove SD card
2. Open MP3 folder
3. Replace file: 0500.mp3
4. Keep the same file name

Your song will now play with triple tap.

### Tips

- Tap quickly for triple tap
- Use high-quality MP3 files
- Keep SD card secure
- Avoid touching sensor during power-up

HAVE A SWELL DAP PAL!



Contact us anytime at [props88.com](http://props88.com)